


## Installing Network Drivers on Windows XP

After the physical installation of the card in your PC you will have to install the drivers for your Windows Operating System. You must be logged-in as Administrator or your login must have Administrator rights.

1. Power on your computer.



2. As the computer is loading Windows XP it will automatically find your new Ethernet card and configure it to work properly. A small dialogue box should appear at the bottom right corner of your desktop to inform you that Windows XP has found your card and has installed it.

If the card doesn't install properly refer to the [Troubleshooting](#) guide. Otherwise continue with [Configuring Network Settings for Windows XP](#).